



SERVICE BULLETIN # 00129

201 INDUSTRIAL BOULEVARD • KEARNEYSVILLE, WV 25430

Phone: (304) 728-7056 • Fax: (304) 725-6579 • Toll Free: (800) 931-9214

PAGE: 1 of 1

DATE: 8-18-00

REVISION: 00

SUBJECT: GII 4 Button Programming (GIIv2) Venders Holding Credit & Not Allowing Vending

MODELS: GII 4 Button Prog. (GIIv2) CDC Venders With External Mode Button

KIT NUMBER

KIT DESCRIPTION

BEFORE WORKING ON VENDER: Remove power from vender by unplugging vender's main power cord from the AC voltage power source (wall outlet).

Reason For Fix:

When tightening the vender's main door, the inner door could possibly press in the mode button (which is mounted to the changer vault next to the H.H.C. phone jack). This will allow credit to be held and will not

Instructions:

1. Remove the nut and washer holding the mode button to the changer vault.
2. Press the mode button through the hole in the changer vault (keep the hand held computer jack mounted to the changer vault).
3. If desired, replace the nut and washer on the mode button now hanging behind the changer vault (to keep with vender).

**ANY QUESTIONS??? CONTACT ROYAL VENDORS' CUSTOMER SERVICE DEPARTMENT
CALL TOLL FREE (800) 931-9214**