



Helpful Hints **0039**

clear & easy

426 INDUSTRIAL BOULEVARD • KEARNEYSVILLE WV 25430-2776 • USA
Phone: +1 304 728-7056 • Fax: +1 304 725-6579 • Toll Free: 800 931-9214

PAGE: 1 of 1

DATE: 7-13-06

REVISION: 00

SUBJECT: Correct Shelf Quantity Setting

of People
Required



MODELS: RVV NG

TOOLS REQUIRED: None

ESTIMATED TIME: <1 minutes



The following areas of this vender contain voltage which can cause serious injury or even death: the main power cord, supplying 110 VAC to the evaporator, EMI filter, and refrigeration system; the power line from the EMI filter to the ballast and transformer; and the ballast, which can produce upwards of 600 volts. Remove power from vender before working in any of these areas.

REASON FOR HELPFUL HINT: On all RVV NG's with -4 or higher software, after entering the Calibration menu, the first item displayed is "Shelf." This submenu item should always be set to "05," but generally it should *never* be entered into. This Helpful Hint describes the correct procedure for setting "Shelf" to "05" in the event this submenu item is ever entered into and changed.

INSTRUCTIONS:

For more detailed programming instructions, refer to the appropriate RVV NG Service and Parts Manual.

1. Enter the Service Menu and scroll to Test Modes. Press <enter>.
2. Scroll to Calibrate. Press <enter>. The display will show Password.
3. Enter the correct password. Press <enter>. The display will show Shelf.
4. Press <enter>. The display will now show the current shelf quantity setting. Ensure it is set to 05. If the display does not show 05, use <up> or <down> to change the quantity to 05. Press <enter>, then press <exit>.

ANY QUESTIONS??? CONTACT ROYAL VENDORS' CUSTOMER SERVICE DEPARTMENT
CALL TOLL FREE (800) 931-9214