



SERVICE BULLETIN # 00155

201 INDUSTRIAL BOULEVARD • KEARNEYSVILLE, WV 25430

Phone: (304) 728-7056 • Fax: (304) 725-6579 • Toll Free: (800) 931-9214

PAGE: 1 of 1

DATE: 8-21-00

REVISION: 02

SUBJECT: Vender Locks Up and Shows "Ice Cold, FrEE" on Digital Display

MODELS: Merlin IV Venders (prior to PO 1442 or Control Board Rev. 41.04 and 40.04)

KIT NUMBER

KIT DESCRIPTION

BEFORE WORKING ON VENDER: Remove power from vender by unplugging vender's main power cord from the AC voltage power source (wall outlet).

Reason for Fix:


In rare instances when the vender is completely sold out, and the door is opened to service / fill the vender, the digital display may show ICE COLD, FrEE.

Instructions:

To Correct this problem:

1. Open the outer door of the machine.
2. Next open the inner door of the machine.
3. On some machines there is a metal cover over the area of the coin mechanism and the control board, remove the sheet metal screws that hold this cover in place.
4. Locate the mode button on the control board.
5. To reset, press the mode button one time, then close door of vender.

Control Board



Button

**ANY QUESTIONS??? CONTACT ROYAL VENDORS' CUSTOMER SERVICE DEPARTMENT
CALL TOLL FREE (800) 931-9214**