

## **SETTING PRICE – GIII KO**

1. Push the mode button on the vender's control board.
2. Push #2 selection until "PASS," input the pass code (4231), then press #4 to enter.
3. Push the #2 selection until "PrIC," then hit the #4 selection to enter.
4. You will see "PR1." This stands for price 1. Price is set by selection number.
5. Push the #2 selection to scroll through selections 1 through 13 or "ALL."
6. If you enter into "ALL," this will change the price on all selections at once.
7. When entering into a single selection or "ALL," you can raise the price by pushing the #2 selection, or lower it by pushing the #3 selection. Press the #4 selection to save the price.
8. Press the #1 selection to exit.