



Helpful Hints **0038**

clear & easy

426 INDUSTRIAL BOULEVARD • KEARNEYSVILLE WV 25430-2776 • USA
Phone: +1 304 728-7056 • Fax: +1 304 725-6579 • Toll Free: 800 931-9214

PAGE: 1 of 1

DATE: 6-5-06

REVISION: 00

SUBJECT: Disabling Milk Merchandiser Health Sensor

of People
Required



MODELS: Milk Merchandisers

TOOLS REQUIRED: None

ESTIMATED TIME: <1 minutes



The following areas of this vender contain voltage which can cause serious injury or even death: the main power cord, supplying 110 VAC to the evaporator, EMI filter, and refrigeration system; the power line from the EMI filter to the ballast and transformer; and the ballast, which can produce upwards of 600 volts. Remove power from vender before working in any of these areas.

REASON FOR HELPFUL HINT: The Milk Merchandiser's health sensor is not required for aseptic products. This Helpful Hint describes the procedure for disabling this health sensor. **NOTE:** *The health sensor cannot be disabled on control boards with EEPROM revision 67199-3 or lower. In order to disable the health sensor on control boards with revision 67199-1, -2, or -3 chips, the chip must be replaced with revision -4 or higher EEPROM.*

INSTRUCTIONS:

For more detailed programming instructions, refer to the Milk Merchandiser Service and Operations Manual.

1. Enter the Service Menu and scroll to the Refrigeration Mode ("FriG"). Press <enter>.
2. Scroll to Disable Health Sensor ("dHS"). Press <enter>.
3. If the health sensor is currently enabled, "1" will be flashing. Press <up> or <down> to change the "1" to "0."
4. Press <exit>, and close the vender's door.

ANY QUESTIONS??? CONTACT ROYAL VENDORS' CUSTOMER SERVICE DEPARTMENT
CALL TOLL FREE (800) 931-9214