



SERVICE BULLETIN 359

426 Industrial Boulevard • Kearneysville WV 25430-2776 • USA
 Telephone: +1 304 728 7056 • technicalinquiry@royalvenders.com
 Toll-free in North America: 1 800 931 9214 • Fax: +1 304 725 4016
 Canada: +1 905 738 5777 • Mexico: +52 55 5203 6887
 Europe: +49 2158 95 1000 • Australia: +61 2 9890 5433

Page: 1 of 2

Date: 8 June 2012

Revision: 00

SUBJECT: GIII Plus Validator Adapter Plate Installation

Number of
People
Required



MODELS: All GIII Plus models

KIT NUMBER

KIT DESCRIPTION

355585SRV

Validator Adapter Plate

TOOLS REQUIRED: 11/32" (9 mm) socket or nut driver

ESTIMATED INSTALLATION TIME: <15 minutes



The following areas of this vender contain voltage which can cause serious injury or even death: the main power cord, supplying 115-230 VAC to the evaporator, EMI filter, and refrigeration system; the power line from the EMI filter to the ballast and transformer; and the ballast, which can produce upwards of 600 volts. Remove all power from the vender before working in any of these areas.

REASON FOR BULLETIN: This bulletin describes the procedure for installing the Validator Adapter Plate, which allows for the installation of both a bill validator and a card reader in the GIII Plus venders.

INSTALLATION INSTRUCTIONS:

NOTE: Before working on the vender, always remove power by unplugging the vender's power cord from the AC voltage source (wall outlet).

1. Unplug the harnessing to the bill validator (if currently installed). Then, using an 11/32" (9 mm) socket or nut driver, remove the four nuts that secure the bill validator. (Refer to Figure 1.) Once these are removed, pull the validator straight out of the door.
2. Remove the four nuts that secure the validator filler plate in the vender's door. (Refer to Figure 1.) Remove the filler plate.
3. Mount the validator adapter plate in the opening where the filler plate was. Secure it with the four nuts that were removed in Step 2. (Refer to Figure 2.)
4. Mount the card reader where the bill validator was previously mounted (lower hole). Secure it with the four nuts that were removed in Step 1.
5. Mount the bill validator onto the validator adapter plate. Secure it with the four nuts from the kit.
6. Connect all harnessing to the validator and to the card reader as required.

In an effort to provide our customers with the latest information on our equipment, Royal Vendors sends service bulletins to customers using the original ship-to address or e-mail addresses, if supplied by our customers. We also post all service bulletins on our website at www.royalvenders.com. If for any reason a vender is moved to another location or is sold to another customer other than to whom Royal Vendors originally sent the machine, it is the responsibility of the original purchaser of the vender to notify the appropriate personnel of the service bulletin.

**ANY QUESTIONS? CONTACT ROYAL VENDORS' CUSTOMER SERVICE DEPARTMENT
 IN NORTH AMERICA, CALL TOLL FREE 1 800 931 9214**



SERVICE BULLETIN 359

426 Industrial Boulevard • Kearneysville WV 25430-2776 • USA
Telephone: +1 304 728 7056 • technicalinquiry@royalvendors.com
Toll-free in North America: 1 800 931 9214 • Fax: +1 304 725 4016
Canada: +1 905 738 5777 • Mexico: +52 55 5203 6887
Europe: +49 2158 95 1000 • Australia: +61 2 9890 5433

Page: 2 of 2


Date: 8 June 2012

Revision: 00

SUBJECT: GIII Plus Card Reader Plate Installation

MODELS: All GIII Plus models

Figure 1.



Validator filler plate nut (4 nuts total)

Remove the four nuts that secure the validator (two on each side).


Figure 2.

Mount the validator adapter plate, as shown, and secure it with the four 11/32" (9 mm) nuts.

Note: Some parts are removed in this illustration for clarity.

Validator adapter plate

11/32" nut
(9 mm)



**ANY QUESTIONS? CONTACT ROYAL VENDORS' CUSTOMER SERVICE DEPARTMENT
IN NORTH AMERICA, CALL TOLL FREE 1 800 931 9214**