



Helpful Hints 0036

clear & easy

426 INDUSTRIAL BOULEVARD • KEARNEYSVILLE WV 25430-2776 • USA
Phone: +1 304 728-7056 • Fax: +1 304 725-6579 • Toll Free: 800 931-9214

PAGE: 1 of 1

DATE: 12 Apr 06

REVISION: 00

SUBJECT: Selection Depth Setting in TDV

MODELS: All Triple-Depth Venders (TDV)

of People
Required



TOOLS REQUIRED: None

ESTIMATED TIME: <5 minutes

REASON FOR HELPFUL HINT: In TDV programming, selection depth settings (SdEP) will *always* revert to “1” (single depth) for all selections which only have front columns assigned to them. If space-to-sales settings are ever changed for any reason, **it is imperative to recheck the depth settings for all selections after (not before) the space-to-sales settings are changed.** If depth settings are not correct, a double-vend or triple-vend situation may occur.

INSTRUCTIONS:

For more detailed programming instructions, refer to the TDV Service and Operations Manual.

1. Reset any space-to-sales (StoS) settings that are to be changed.
2. Access the selection depth mode (SdEP). Check all selections for proper depth settings (“1” = single depth, “2” = double depth, “3” = triple depth).
3. Test vend for product reliability.

Note: *All selections with only front columns assigned will automatically revert to “1” in selection depth mode. All selections with at least one rear column assigned will maintain the depth setting that was set in SdEP.*

ANY QUESTIONS??? CONTACT ROYAL VENDORS' CUSTOMER SERVICE DEPARTMENT
CALL TOLL FREE (800) 931-9214